

bawdy *lines*

Desire

Instructions



Overview

This model is a vibrating massager product: it is composed of an inner core, circuit board, motor, lithium battery, silicone skin and data cable. The inner core of the main body is nylon material, and the main body has a built-in 030 motor, which is controlled by a 10-frequency mode circuit board.

Instructions

1. Charge before use, the indicator light will flash when charging, and it will be on when it is full.
2. Long press the power button for 1.5 seconds to turn on, short press the FM, ten-frequency cycle.
3. Long press the power button for 1.5 seconds to shut down, the motor stops working, and the light goes out.
4. Charging method: USB interface to 2.5mm mono plug for charging.

Additional Information

Waterproof level : Silicone sleeve main body IPX6
Standard : ROHS、CE
Use environment : 0-40℃

Details

Silicone raw materials meet the relevant FDA standards



Power button



DC

Charging jack

Product Specifications

Electrical performance	
Product Size	80*50*40mm
Product Weight	126G
Charging Voltage	5.0V
Charging Time	2H
Battery Capacity	≤300mah
Operating Voltage	3.7V
Battery Life	45-55min
<p>Please note:</p> <ol style="list-style-type: none">1. For the first operation, it must be fully charged before use.2. Select and use a USB charging plug of national standard with a voltage of 5v for charging.3. Do not operate any function keys or be in contact with water while charging.	

